







面板背视



I		
FU:2	1	101
BP:21	2	
	3	
KA1:1	4	107
KA1:2	5	109
KA5:6	6	
KA2:3	7	111
	8	
HG:1	9	117
HR:1	10	119
HY:1	11	121
HG:2	12	N
	13	
	14	
HY:2	15	N
BP:1	16	71
BP:3	17	73
BP:2	18	75
	19	屏蔽层
BP:10	20	77
BP:11	21	79
	22	屏蔽层
BP:12	23	81
BP:13	24	83
	25	屏蔽层
KA2:2	26	53
BP:16	27	59
KA2:5	28	131
KA2:6	29	133
KA3:5	30	135
KA3:6	31	137
KA4:5	32	139
KA4:6	33	141
KM:1	34	143
KM:2	35	145
	36	
	37	
	38	
	39	
	40	

柜内如多回路，  
需在线号前加“1-;2-”零线也需区分

N 至零排

V2 接线图	
制	册
修	编
版	号
2025.01	册